

ΟΔΗΓΟΣ ΕΠΙΛΟΓΗΣ ΣΗΜΑΔΟΥΡΑΣ / FENDER-BUOY GUIDE

	 A	 F	 G
- 10'	AB0	F01	G2
11-16'	AB0 A1	F01 F1	G2 G3
17-23'	A1 A2 A3	F1 F02 F2	G3 G4 G5
24-30'	A3 A4	F2 F3 F4	G5
31-45'	A4 A5	F5 F6	
46-60'	A5 A6	F7 F8	
61'+	A7	F11 F13	